

การตั้งค่า Port Forwarding ของ GPON ZTE F668

1. เปิด Browser พิมพ์ `http://192.168.1.1` ที่ช่อง URL แล้วกด Enter จะแสดงหน้า Login ดังรูป
พิมพ์ Account = admin และ Password = password



2. คลิกเมนู Application



3. ที่เมนู **Port Forwarding** คลิก **Enable** และตั้งค่าตามที่ต้องการใช้งาน เช่น

- **Name** ตั้งชื่อ การทำ forward port ชุดนี้
- **Protocol** เลือก Service ที่ใช้งาน
- **WAN Host Start IP Address** = 0.0.0.0 หรือ ว่างไว้ (เนื่องจาก WAN IP มีการเปลี่ยนทุกรอบ 24 ชั่วโมง)
- **WAN Host End IP Address** = 0.0.0.0 หรือ ว่างไว้ (เนื่องจาก WAN IP มีการเปลี่ยนทุกรอบ 24 ชั่วโมง)
- **WAN Connection** เลือกที่ตรงกับชื่อที่ใช้งานออก internet
- **WAN Start Port** ระบุตาม Service ที่ต้องการใช้งาน
- **WAN End Port** ระบุตาม Service ที่ต้องการใช้งาน
- **LAN Host IP Address** พิมพ์ IP ของเครื่องที่ต้องการใช้งาน forward port
- **LAN Host Start Port** และ **End Port** อาจจะระบุตาม **WAN Start Port ,End Port** หรือวิธีการออกแบบตามต้องการ

Path: Application-Port Forwarding 中文 Logout

Enable

Name

Protocol **TCP**

WAN Host Start IP Address

WAN Host End IP Address

WAN Connection **omci_ipv4_pppoe_1**

WAN Start Port (1 ~ 65535)

WAN End Port (1 ~ 65535)

Enable MAC Mapping

LAN Host IP Address

LAN Host Start Port (1 ~ 65535)

LAN Host End Port (1 ~ 65535)

Enable	Name	WAN Host Start IP Address	WAN Start Port	LAN Host Start Port	WAN Connection	Modify	Delete
	Protocol	WAN Host End IP Address	WAN End Port	LAN Host End Port	LAN Host Address		
There is no data, please add one first.							