

## วิธีการตั้งค่า Forwarding ของ Technicolor 7200.20

1. เปิด Browser และใส่ช่อง Address พิมพ์ <http://192.168.0.1> > Enter , พิมพ์ Password = admin แล้วคลิก OK  
หมายเหตุ : กรณีที่ใช้ Browser IE อาจจะพบปัญหาในการตั้งค่า ให้ใช้ Browser อื่นแทน



## 2. เมนู Advanced > Forwarding

- a. External IP Address = 0.0.0.0
- b. เลือก Service Name
- c. คลิก Add
- d. ตั้งค่า Port ตามต้องการ
- e. คลิก Apply

หมายเหตุ External IP Address หมายถึง IP WAN ซึ่งมีการเปลี่ยนทุกๆ 24 ชั่วโมง จึงไม่ควรระบุค่าใดๆ

**Advanced**

**Forwarding** : This page allows for incoming requests on specific port numbers to reach web servers, FTP servers, mail servers, etc. so they can be accessible from the public internet. A table of commonly used port numbers is also provided.

**Known Rule Adder**

Local IP Address: 192.168.0.12  
External IP Address: 0.0.0.0  
Service Name: AIM Talk

**Add**

Local IP Address: 192.168.0.12  
Local Start Port: 5001  
Local End Port: 5001  
External IP: 0.0.0.0  
External Start Port: 5001  
External End Port: 5001  
Protocol: BOTH  
Description:  
Enabled: On

**Cancel** **Apply**

Internal			External			Protocol	Description	Enabled		Remove All
IP Address	Start Port	End Port	IP Address	Start Port	End Port					
192.168.0.12	5001	5001	0.0.0.0	5001	5001	BOTH		Yes	Edit	Remove

**UPNP port mapping**

Protocol	Start Port	End Port	Description
----------	------------	----------	-------------