



วิธีการ Forward Port ของ Modem ZTE ZXV10 W300

1. เปิดเว็บเบราว์เซอร์ เช่น Internet Explorer , Fire Fox , Chrome 
2. พิมพ์ http://192.168.1.1 ที่ช่อง Address และกด Enter > จะขึ้นให้ Login พิมพ์ Username = admin / Password = password > และคลิกที่ปุ่ม OK



3. คลิกที่แถบ Advance > คลิกที่ NAT > และคลิกที่ Virtual Server



4. Start Port และ End Port ใส่เลข Port ที่ต้องการ > Local IP Address พิมพ์หมายเลข IP Address ในวง Lan ที่ต้องการ Fix ไว้ที่ตัวอุปกรณ์ > และกดที่ปุ่ม APPLY จะแสดงขึ้นมาใน List

ZTE中兴

Advanced | Quick Start | Interface Setup | **Advanced Setup** | Access Management | Maintenance | Status

Firewall | Routing | NAT | ADSL | QoS | PortBinding | Pvid Setting

Virtual Server

Virtual Server for : Single IPs Account/ PVC0

Start Port Number : 23

End Port Number : 23

Local IP Address : 192.168.1.35

Virtual Server Listing

Rule	Start Port	End port	Local IP Address	Edit	Drop
0	23	23	192.168.1.35		
1	N/A	N/A	N/A		
2	N/A	N/A	N/A		
3	N/A	N/A	N/A		
4	N/A	N/A	N/A		
5	N/A	N/A	N/A		
6	N/A	N/A	N/A		
7	N/A	N/A	N/A		
8	N/A	N/A	N/A		
9	N/A	N/A	N/A		

APPLY | BACK | CANCEL