

How to set up general setting on Set-top box PSI True TV (V1)

1. Press On/ Off button on remote control

2. Select Channel/ Adjust Volume

- Select channel by using Up/ Down arrow or number 0-9
- Adjust volume by using Left/ Right arrow



3. Change Mode between TV/ Radio

- Press TV/R to select between TV and Radio
- Press Up/ Down arrow to change between TV channel and Radio channel



4. Button to select channel mode

- Press SM to enter Smart Move mode
- Press SM to change channel mode between PSI TV and True TV
- Press Up/ Down arrow to select desired channel mode and then press OK



5. Temporary mute / restore to factory settings

- Temporary mute
 - Press MUTE to turn off sound
 - Press MUTE again to cancel Mute
- Restore to factory settings
 - Press and hold MUTE button for 10 seconds, a message to confirm whether to restore to factory settings appears
 - Move arrow to 'agree' and then press OK



6. Adjust sound volume

- Press R/L button, there'll be sound setup menu
- Move the arrow to sound channel
- Move the arrow to select desired sound channel
- Press 'Exit' button to leave a menu



7. Auto update channel

- Press and hold OTA button for 10 seconds, there'll be message Downloading software and wait a moment. Don't turn it off
- After downloading process completed, the receiver will restart and return to normal status

